

**GaN MMIC Pulse Power Amplifier** 8-18GHz

#### **Features**

Frequency: 8-18GHz

• Small Signal Gain: 31dB Typical Power Gain: 18dB Typical • Gain Flatness: ±2.0dB Typical

Psat: 46dBm Typical

• Pulse: 10% Duty Cycle 500us width

• PRF (Pulse Repetition Frequency) 10KHz

PAE:25%

Supply Voltage:

VD=+28V@0.16A(Pulse), VG=-1.75V

• Input/Output: 50Ω

Die Size: 3.6 x 5.0 x 0.1mm

### **Typical Applications**

• Test Instrumentation

Microwave Radio & VSAT


Military & Space


Telecom Infrastructure

Fiber Optics

# **Electrical Specifications**

TA = +25°C, VD=+28V, IDD =0.16A Typical, 10% Duty Cycle, 1KHz PRF 500us Pulse Width









V1.0.0

GaN MMIC Pulse Power Amplifier 8-18GHz


# Pout vs. Frequency(Pin=28dBm)




## Gain vs. Frequency




### VSWR vs. Frequency



### PAE vs. Frequency



### **Current vs. Frequency**



MILLER MMIC INC.

www.millermmic.com

Sales: sales@millermmic.com



V1.0.0

GaN MMIC Pulse Power Amplifier 8-18GHz

#### **Absolute Maximum Ratings**

Drain Bias Voltage (VD)	+30V
Gate Bias Voltages(VG)	-5V
Drain Current (IDD)	5.5A
RF Input Power (RFIN)@(+28V)	+30dBm
Channel Temperature	225 °C
Junction Temperature	310 °C
Operating Temperature	-55°C to +85 °C
Storage Temperature	-55°C to +175 °C

# **Typical Supply Current vs. VD,VG**

VD (V)	VG (V)	IDD (mA)
+28	-1.75	160



ELECTROSTATIC SENSITIVE DEVICE OBSERVE HANDLING PRECAUTIONS

MILLER MMIC INC. www.millermmic.com

Sales: sales@millermmic.com




/1.0.0

GaN MMIC Pulse Power Amplifier 8-18GHz

# **Outline Drawing:**

All Dimensions in  $\mu m$ 



#### Notes:

1. Die size: 3600\*5000 μm

Input RF Pad size: 100\*100 μm
Output RF Pad size: 100\*150 μm
VG1 pad size: 100\*100 μm
VD1 pad size: 100\*100 μm
VD2 pad size: 120\*100 μm
VD3 pad size: 100\*150 μm

8. GSG: 150 μm


9. Bond pad metalization: Gold 10.Backside metalization: Gold



/1.0.0

GaN MMIC Pulse Power Amplifier 8-18GHz

# **Assembly Drawing**



No.	Mnemonic	Description
1	RF IN	Signal input terminal, connected to $50\Omega$ circuit.
2	RF OUT	Signal output terminal, connected to $50\Omega$ circuit.
3	VD	Drain voltage, bias network is required; see Application Circuit on.
4	VG	Gate voltage, bias network is required; see Application Circuit on.
5	Die Bottom	Die bottom must be connected to RF and dc ground.

MILLER MMIC INC.

www.millermmic.com

Sales: sales@millermmic.com



V1.0.

GaN MMIC Pulse Power Amplifier 8-18GHz

#### Miller MMIC Inc. All rights reserved

Miller MMIC, Inc. holds exclusive rights to the information presented in its Data Sheet and any accompanying materials. As a premier supplier of cutting-edge RF solutions, Miller MMIC has made this information easily accessible to its clients.

Although Miller MMIC believes the information provided in its Data Sheet to be trustworthy, the company does not offer any guarantees as to its accuracy. Therefore, Miller MMIC bears no responsibility for the use of this information. It is worth mentioning that the information within the Data Sheet may be altered without prior notification.

Customers are encouraged to obtain and verify the most recent and pertinent information before placing any orders for Miller MMIC products. The information in the Data Sheet does not confer, either explicitly or implicitly, any rights or licenses with regards to patents or other forms of intellectual property to any third party.

The information provided in the Data Sheet, or its utilization, does not bestow any patent rights, licenses, or other forms of intellectual property rights to any individual or entity, whether in regards to the information itself or anything described by such information. Furthermore, Miller MMIC products are not intended for use as critical components in applications where failure could result in severe injury or death, such as medical or life-saving equipment, or life-sustaining applications, or in any situation where failure could cause serious personal injury or death.